

If your sunroof gets stuck especially in the open position:

There is a key for manual operation of the sunroof. The key is stored in the fuse box 'cupboard' below the matrix of fuses. It is clipped into place with two spring clips. The key has a Philips (or crosspoint) screwdriver at one end and a 4mm Allen (hex) key on the other.




Photo1

Remove the light fitting using the Philips end of the key. This exposes the motor and gearbox. Insert the allen key in the cream coloured plastic disc. Disengage the clutch by moving the silver lever from its rest position through 90 deg clockwise. Turn the crank handle in the appropriate direction until the sunroof is closed (or open as appropriate)



Photo2